

A140



A540



Connect the STB to your TV using one of the options below.



Good - Coaxial Cable

Connect one end of the coaxial cable to RF Out on the STB and the other to the RF IN on your TV (consult your TV manual). Your TV will need to be tuned to channel 3 in order to view programming. This is a Non HD connection.



Better - Analog AV cable

Composite Non HD Video/Audio (yellow=video, white=left audio and black=right audio)

Component HD Video/Audio (red, blue, green=video white=left audio and black=right audio).

Connect the specialized cable end to the AV output of the STB and the other ends to your TV using either composite in or component in on your TV. This will require that your TV to be set to a video input of Video or COMP in order to view programming (consult your TV manual).



Best - HDMI Cable

Digital Video and audio HD delivery. Connect one end of the HDMI cable to the HDMI port on the STB and the other to your TV. This will require that your TV to be set to a video input of HDMI in order to view programming (consult your TV manual).

Connect the included power cord to the power supply port on the STB and the other end to a working electrical outlet.